



Manufacturers Contact:

Sno-Safe Snow Guards LLC
 PO Box 541
 Chicopee, MA 01021
 Phone: 413-592-0404
 Email: info@sno-safe.com

Colors:

Available in Clear and Standard Colors

Fastening Methods:

1. Surebond SB-190 Adhesive
2. Mechanical Fastening with Self Tapping Roofing Screws using provided holes
3. Lucas #6600 Adhesive w / TPO primer for TPO Roofs

Use on:

Metal, Rubber, TPO, PVC, Glass

Installation:

- Adhesive Only or Adhesive & Screws

Strength:

Gusseted & thick wall design for maximum strength

Lasting:

UV inhibitor prevents discoloration & Degradation from sunlight

Request for manufacturers Layout/Spacing at: <https://sno-safe.com/spacing.html>

Material:	UV Resistant Polycarbonate
Manufacturing method:	Injection Molding
Shear Load Testing:	2410 lbs., Adhesive Only 2480 lbs., Adhesive & Screws
Installation Process:	See installation instructions
SureBond strength vs. cure time (approx.)	20% @ 2 weeks, 35% @ 4 weeks, 60% @ 6 weeks, Full cure @ 12 weeks
Suggested Layout/Spacing	Roof dependent. See calculator @ https://sno-safe.com/spacing.html