



Colors: Available in Clear and Standard Colors

- Fastening Methods:
1. Surebond SB-190 Adhesive
 2. Mechanical Fastening with Self Tapping Roofing Screws using provided holes
 3. Lucas #6600 Adhesive w / TPO primer for TPO Roofs

Use on: Metal, Rubber, TPO, PVC, Glass

Request for manufacturers Layout/Spacing at: <https://sno-safe.com/spacing.html>

Manufacturers Contact: Sno-Safe Snow Guards LLC
 PO Box 541
 Chicopee, MA 01021
 Phone: 413-592-0404
 Email: info@sno-safe.com

Material: UV Resistant Polycarbonate	PROJECT			
	Sno-Safe Snow Guards LLC			
Dimensions: Inches (unless otherwise specified)	TITLE			
	Sno-Safe Original			
APPROVED	SIZE	CODE	DWG NO	REV
CHECKED	B		Sno-Safe-001	
DRAWN Robert Casey	7-26-21	SCALE 1:1	WEIGHT	SHEET 1/1